

Roland DGA Solvent Gloss Canvas: ESM-SGC2

Product Overview

Roland DGA ESM-SGC2 is a high-quality, true artist canvas with a gloss finish. This 65% polyester/35% cotton blend is 22 mils thick and 11.5 oz/sq. yd. (390 gsm). It is durable, waterproof, and can be stretched without cracking. It also has excellent archival properties. This solvent-printable canvas has a specialized acrylic coating that yields superior color brilliance and excellent image definition.

Specifications

Thickness: 22 mil

Finish: Gloss

Basis Weight: 11.5 oz/sq. yd. (390 gsm)

Weave: Oxford

Blend: 65% polyester/35% cotton

Color: Natural White

Core Diameter: 3"

Shelf Life: 1 year

Ink Compatibility: Eco-Sol MAX2, EJ, TR2, Eco-UV

Available Sizes: 30" x 99'; 54" x 99'

Applications

Fine Art/Photographic

Home/Office Décor

POP Displays

Window Coverings

Wall Coverings/Murals

Tradeshow Graphics

Part Numbers

ESM-SGC2-99-30

ESM-SGC2-99-54

Storage Conditions

ESM-SGC2 Roland DGA Solvent Gloss Canvas should be handled with care to prevent surface contamination that may affect the printable surface of the product. This material should be processed and stored in an environment of 65° - 85° F (18° - 29° C) and 30 - 50% relative humidity (non-condensing) that is clean and relatively dust-free. We recommend storing this product in its original packaging in a cool, dry area until ready for use. If storage conditions are outside the recommended operating ranges, allow the material to acclimate to the production environment for at least 24 to 48 hours before use.

Roland Certified Media Guarantee

This product is sold for the usage of the applications stated in this document. Please note that canvas is a natural product that may expand or shrink with environment. Liquid laminates can be used, but it should be pre-tested since some may cause yellowing or cracking over time.